


MXFDH2528H-602 MX FUEL Breaker Kit IN2

4933464877 - MXFDH2528H-602 - 4000468191





Position	Quantity	Description	Part number	EAN
0004 1	1	RATING PLATE	4931476023	4058546343781
0005 2	8	SCREW	4931476090	4058546338657
0007 3	2	SCREW	4931624491	4002395758142
0008 4	2	WASHER	4931455939	4058546244934
0009 5	1	RING	4931463643	4058546045791
0010 6	1	SCREW	4931468352	4058546291402
0011 7	7	SCREW	4931468355	4058546291433
0012 8	2	MARKER	4931468286	4058546286149
0014 9	1	SCREW	4931468352	4058546291402
0015 10	1	BEARING END PLATE	4931468209	4058546271299
0016 11	7	SCREW	4931468355	4058546291433
0017 12	1	SCREW	4931624491	4002395758142
0018 13	4	SCREW	4931468352	4058546291402
0019 14	1	STATOR	4931476231	4058546359836
0020 15	1	STICKER	4931463581	4058546045562
0021 16	1	GRIP CLAMP	4931463500	4058546045289
0022 17	2	SCREW	4931468832	4058546300654
0023 18	1	O-RING	4931463476	4058546045180
0024 19	1	SCREW	4931463194	4058546242022
0025 20	3	SCREW	4931468261	4058546343774
0026 21	1	RING	4931463644	4058546045807
0027 22	3	GRIP CLAMP	4931463500	4058546045289
0028 23	8	SCREW	4931468832	4058546300654
0029 24	1	WORK LAMP	4931468229	4058546271442
0030 25	1	WORK LAMP	4931468230	4058546271459
0031 26	1	HOUSING FOR BATTERY	4931468295	4058546271657
0032 27	1	SCREW	4931468296	4058546286156
0033 28	1	BATTERY	4931468297	4058546286163
0034 29	2	SCREW	4931624538	4002395760039
0035 30	6	SCREW	4931468355	4058546291433
0036 31	1	SCREW	4931468352	4058546291402
0037 32	2	SCREW	4931468832	4058546300654
0038 33	1	RUBBER SLEEVE	4931468208	4058546271282
0039 34	1	O-RING	4931463651	4058546045852
0040 35	1	RETAINING RING	4931468207	4058546286057
0041 36	1	BEARING	4931468211	4058546286071
0042 37	1	SEAL RING	4931468834	4058546300678
0043 38	1	PIN	4931463425	4058546045012
0044 39	1	PARALLEL KEY	4931463428	4058546045036
0045 40	1	GROOVED BALL BEAR.	4931463654	4058546045869
0046 41	1	COVER	4931468226	4058546271428
0115 42	1	HOUSING	4931468221	4058546271374
0120 43	1	ROCKER BAR	4931476091	4058546338664
0125 44	1	ROCKER BAR	4931468232	4058546286101
0135 45	4	CYLINDER	4931463605	4058546045685
0190 46	1	HOSE	4931468350	4058546291389
0195 47	1	INTAKE MANIFOLD	4931468234	4058546271480
0200 48	1	WASHER	4931463422	4058546044992
0205 49	10	SCREW	4931463507	4058546045340
0210 50	6	SCREW	4931463506	4058546045333

Position	Quantity	Description	Part number	EAN
0215 51	1	SCREW	4931463424	4058546045005
0225 52	1	SCREW	4931463427	4058546045029
0230 53	4	SCREW	4931463546	4058546045494
0231 54	1	SCREW	4931476230	4058546346706
0235 55	1	WASHER	4931463477	4058546045197
0240 56	2	GROOV. BALL BEARING	4931463435	4058546045067
0245 57	1	COVER	4931463562	4058546045524
0265 58	1	CRANKCASE	4931468071	4058546291624
0275 59	1	SEAL	4931463563	4058546045531
0280 60	1	SPACER	4931468058	4058546291266
0285 61	1	STOP	4931463552	4058546045500
0290 62	1	WASHER	4931468060	4058546323912
0295 63	1	GEAR	4931468061	4058546291273
0300 64	1	GEAR	4931468212	4058546271305
0310 65	1	NEEDLE BUSH	4931463475	4058546045173
0320 66	2	BELLOWS	4931468233	4058546271473
0325 67	1	WASHER	4931463422	4058546044992
0330 68	1	GEAR FLANCE	4931468272	4058546271534
0340 69	1	RIGHT HANDLE HALF	4931476059	4058546338695
0345 70	1	ELECTRONIC	4931476065	4058546338701
0350 71	1	LEFT HANDLE HALF	4931476060	4058546338718
0355 72	1	COVER	4931476066	4058546338725
0360 73	1	SWITCH	4931476061	4058546338732
0365 74	1	CRANK ASSEMBLY	4931476067	4058546338749
0370 75	1	CAP	4931476062	4058546338756
0375 76	1	RING	4931463646	4058546045821
0380 77	1	CAP	4931476063	4058546338770
0385 78	1	PLATE SPRING	4931468833	4058546300661
0390 79	1	CLAMP	4931476233	4058546346713
0395 80	1	sensor	4931476070	4058546338800
0400 81	1	ARMATURE	4931476072	4058546338817
0415 82	1	ELECTRONIC	4931476075	4058546338831
0430 83	1	CONNECTING ROD	4931468255	4058546271527
0435 84	1	BATTERY RAIL KIT	4931476078	4058546338879
0440 85	1	INTERLOCK SLEEVE	4931476079	4058546338886
0445 86	1	EJECTOR KIT	4931476080	4058546338893
0600 87	1	CYLINDER	4931468068	4058546271169
0605 88	1	BUSH	4931468076	4058546271190
0615 89	2	O-RING	4931463545	4058546045487
0620 90	1	STRIKER	4931468069	4058546271176
0625 91	1	PISTON	4931468070	4058546271183
0630 92	1	BOLT	4931468065	4058546291297
0635 93	1	SPRING RING	4931463538	4058546045463
0640 94	2	SCREW	4931463035	4058546036324
0700 95	1	TOOL ACCEPTANCE	4931468196	4058546286040
0701 96	1	TOOL ACCEPTANCE	4931468251	4058546286132
0702 97	1	FLANGE	4931463038	4058546036348
0703 98	1	RING	4931463009	4058546036294
0704 99	1	RING	4931463010	4058546036300
0705 100	1	TOOL ACCEPTANCE	4931463037	4058546036331

Position	Quantity	Description	Part number	EAN
0706 101	1	HOLDING BRACKET	4931476210	4058546343736
0707 102	2	DAMPING RING	4931463967	4058546291075
0708 103	1	LOCKING BOLT	4931468216	4058546286088
0709 104	1	COLLAR	4931463493	4058546045258